

# DRIVER FUELING SAFETY INSTRUCTIONS

## ROGUE CLEAN FUELS, LLC



When on Rogue Clean Fuels fueling station premises, do not light matches, smoke cigarettes or use cell phones, and refrain from re-entering a vehicle during fueling. The mixture of Compressed Natural Gas (CNG) and air is flammable. Therefore it is critical to keep ignition sources away from CNG.

In the unlikely event of a CNG fire, evacuate the immediate area of the fire, press the emergency shutdown device and call 911. Do not attempt to disconnect the nozzle from the vehicle. Do not try to extinguish the fire unless you are specifically trained to do so — especially if the fire is near fueling or storage equipment.

If you suspect a gas release at the dispenser, close the nozzle valve and turn the dispenser shutoff valve a quarter-turn to the “off” position. Next, disconnect the fueling nozzle from the vehicle, and reattach it to the mounting bracket on the dispenser. Once the leak is stopped, report the situation to the maintenance technician at (541) 944-2821.

### Emergency Action Plan

Human safety is our number one priority. A windsock is located on the pole next to the equipment cage area. Note the direction of the wind when coming on site. In the event of a fire or gas release:

- Shut off the gas supply by pressing one of the four emergency shut down switches and evacuate up-wind from the fire or gas release.
- Call 911 and report the emergency. The location address is 1125 Anthony Way in White City, Oregon.

### Safety Equipment

- There are four emergency shut down switches and four fire extinguishers on site — one on each canopy pole, one on the light pole to the west side of the property, and one on the pole adjacent to the equipment cage.
- Each fuel dispenser has a gas shut off valve.
- Signs are clearly posted at each pump with safety instructions that drivers must follow.

### Driver Responsibilities

- No smoking
- Shut off vehicle motor
- Follow vehicle fueling instructions
- Follow all posted safety instructions
- Follow pavement directional arrows

Vehicles using Rogue Clean Fuels fueling station must have the CNG fuel tanks inspected every three years or every 36,000 miles.

---

Company Name

---

Driver Signature

---

Date